

**Release Notes
ATLAS Compiler
Version 3.23.23 (20060801)
01 August 2006**

1 Overview

The following describes an overview of changes included within version 20060801 (3.23.23) of the following ATLAS compiler(s)

CASS / RT
IFTE / PAWS

and version 20060801 (3.23.23) of the following ATLAS support tools.

Switch / Ita Compiler

1.1 Enhancements

1.2 Problem Reports

06-053, 06-059, 06-063, 06-064 and 06-999.

2.0 Detailed Description

2.1 Enhancements

2.2 Problem Reports

2.2.1 06-053 and 06-059 – SUBFILE had to start on first column (CASS)

Leading spaces before SUBFILE in the LU file are ignored. Warnings for SUBFILE sections other than 2 are generated. Fix was made in the Switch / Ita Compiler.

2.2.2 06-063 – File type ATG I-O not accepted (IFTE)

Accepts I-O in REQUIRE for file type ATG now. There is still an expectation that file type ATG will only be used in INPUT mode.

2.2.3 06-064 – TRIG as port and pin (IFTE)

Fixed in the IFTE compiler.

2.2.4 06-999 – IDENTIFY after BEGIN, ATLAS (CASS)

IDENTIFY immediately after BEGIN, ATLAS was generating a warning.
This has been fixed.